

TELEX[®] UHF Wireless Intercom

World Wide Frequency Band Chart

All frequency combinations in green character do have CE approval and can be sold in all EU countries.
To use the products the user may have to contact the local authority and request for a frequency licences.

	BTR-80N BTR-1 RKP-4B	NTSC TV CHANNEL	START FREQUENCY	END FREQUENCY	BTR-800 BTR-700	PAL TV CHANNEL	
		14	470	476	88	21 470-478	
		15	476	482		22 478-486	
<p style="text-align: center;">BTR-80N</p> <p>The BTR-80N system is offered on 32 standard frequency band splits:</p> <p style="text-align: center;">F1, F2, F3, F4, F5, F6* H1, H2, H3, H4, H5, H6* A1, A2, A3, A4, A5, A6* B2, B3, B4, B5, B6* C3, C4, C5, C6* D4, D5, D6* E5, E6*</p>	F	16	482	488	F	23 486-494	
		17	488	494		24 494-502	
		18	494	500		25 502-510	
	H	H	19	500	506	H	26 510-518
			20	506	512		27 518-526
			21	512	518		28 526-534
	A	A	22	518	524	A	29 534-542
			23	524	530		30 542-550
			24	530	536		31 550-558
	B	B	25	536	542	B	32 558-566
			26	542	548		33 566-574
			27	548	554		34 574-582
	C	C	28	554	560	C	35 582-590
			29	560	566		36 590-598
			30	566	572		37 598-606
	<p style="text-align: center;">BTR-800 and BTR-700</p> <p>The BTR-800 system is offered on 18 different frequency band splits:</p> <p style="text-align: center;">F1, F2, F3, F4 H1, H2, H3, H4 A2, A3, A4 B3, B4, B6* C3, C4, C6* E88</p> <p>The BTR-700 system is offered on 5 standard frequency band splits:</p> <p style="text-align: center;">A2, B4, C3, C6*, G9*</p>	D	31	572	578	E	38 606-614
			32	578	584		39 614-622
			33	584	590		40 622-630
E		E	34	590	596	E	41 630-638
			35	596	602		42 638-646
			36	602	608		43 646-654
NOT USED IN USA		NOT USED IN USA	37	608	614	NOT USED IN USA	44 654-662
1		1	38	614	620	1	45 662-670
			39	620	626		46 670-678
			40	626	632		47 678-686
2		2	41	632	638	2	48 686-694
			42	638	644		49 694-702
	43		644	650	50 702-710		
3	3	44	650	656	3	51 710-718	
		45	656	662		52 718-726	
		46	662	668		53 726-734	
4	4	47	668	674	4	54 734-742	
		48	674	680		55 742-750	
		49	680	686		61 790-798	
5	5	50	686	692	6	62 798-806	
		51	692	698		63 806-814	
						67 838-846	
6	6	53	704	710	6	68 846-854	
		54	710	716		69 854-862	
		55	716	722			
<p style="text-align: center;">BTR-1 and RKP-4B</p> <p>The BTR-1 systems are offered on 25 standard frequency band splits and the RKP-4B systems are offered on 34 frequency band splits:</p> <p style="text-align: center;">F1, F2, F3, F4, F5 H1, H2, H3, H4, H5 A1**, A2, A3, A4, A5 B2**, B3, B4, B5 C3**, C4, C5 D4**, D5 E5**</p> <p>** A1, B2, C3, D4, E5 frequency bands are for use with BTR-1 systems only</p>	G				G		
						G	
	796-814 GERMANY	796-814 GERMANY		794	800		796-814 GERMANY
				800	806		
				806	812		
	844-862 GERMANY	844-862 GERMANY		812	818	844-862 GERMANY	
	9	9		842	848	9	
				848	854		
				854	860		
			860	866			